
SERIAL DATA
INTERFACE BOARD
SCA
AUX
MOTHER BOARD
SOUND
PROC. BOARD
VIDEO
P4 J4
HOPPER MOTOR
COIN OUT SW
HOPPER WT. SWITCH
16 PIN RIBBON CABLE TO SOUND BD.
JUMPER PLUG
JUMPER PLUG
J.P. RESET SWITCH
DISPLAY SWITCH
FAN
TO MOTHER BD.
TR 120
TR 10
TO BELL
STARTER
BALLAST
POWER CORD
TB 2
SOUND BD
16 PIN RIBBON CABLE TO MOTHER BD - SOUND


DOOR
CABINET
COIN IN SWITCH
CANCEL
HOLD 1
HOLD 2
HOLD 3
HOLD 4
HOLD 5
HOLD 6
DEAL
608 006 00
LOCK OUT COIL
600 007 00
SPEAKER
BELL
J1
MONITOR
600 003 00
FT-8
FT-8
UPPER LIGHT PANEL (REF)
600 006 00
600006 00
FT-8
FT-8
TB1
LOWER LIGHT PANEL (REF)
TB2-9
CR BKR
D-1
TB2-7
D-6
FLUORESCENT LAMP
FT-8
DOOR
CABINET