

## Commboard Clear

To perform a Commboard Clear, follow these steps.

1. Open the Main door.
2. Turn the machine power off.
3. Open the Logic box door.
4. Remove the Commboard.
5. Replace the Commboard software (U34 + U35) with the Commboard Clear eproms.
6. Reinstall the Commboard and turn the machine power on.
7. After 5-10 seconds the left LED (D19) begins to flash.
8. Turn the machine power off.
9. Remove the Commboard.
10. Replace the Commboard Clear eproms (U34 + U35) with the Commboard software.
11. Reinstall the Commboard and turn the machine power on.

**Note:**

**It is strongly recommended to carry out the Commboard Clear together with a Ram Reset!**