IGT Progressive Controller
Game Software Setup

This card was created as a quick reference for common IGT Progressive Controller (IPC) game setup functions.

Note: *Some of the options on this card may or may not be available, depending on the particular paytable activated or software version you have installed.*

Related Documentation

For additional information, see the following related IGT documentation:

- *IGT Progressive Controller Operator's Guide* (p/n 821-363-XX)

- *IGT Progressive Controller EZ Setup User's Manual* (p/n 821-369-XX)

For further information, contact your IGT representative. For viewing and downloading product information, including the most recently updated technical documentation, visit IGT online at **www.IGT.com**.

Internet:	**www.IGT.com**
E-mail:	**Marketing@IGT.com**
Tel:	**775-448-1729**
North America:	**1-800-688-7890**
International:	**1-800-342-5694**

IGT

Game Setup

Machine Serial Number Setup

1. In the Key Chip menu, press the COMM OPTIONS button.

2. Press the SERIAL NO. button.

3. Use the keypad to enter a unique machine ID number.

Machine Setup

1. Verify a valid accounting denomination is set.

2. In the Key Chip menu, press the COMM OPTIONS button.

3. Press the IPC CONFIG button.

4. Press the IPC POLL ADDRESS button. A non-zero address should appear after the word "Address."

5. Press the IPC CONFIG button.

6. After several seconds, the screen displays the word PASSED or lists an error message.

7. Press the EXIT button to return to the Key Chip menu.

8. Verify the progressive setup by pressing MACHINE OPTIONS and then the PROGRESSIVE SETUP button.

Link Down Condition

When a machine experiences a communication disruption for more than eight seconds, it goes into "Link Down" condition, and the ADDRESS button appears. This condition should clear itself once communication to the machine is reestablished.

If this condition does not clear itself when "Link Down" ends:

1. Remove the non responding machine address from the IPC terminal.

2. Repeat *Machine Setup* steps 1-4.